Replace Telco Cabinet

Place Pit to intercept ducts

PROPOSED CABINET LOCATION

Bore Through PUE from
Pole to New Cabinet.

UTILITY POLE W/O WORK LOCATION